


- Your Home Screen w/Default Settings (your home screen icons may vary).



- Adjust the desired options for your application (finishing, duplex, etc...).




- After options are chosen, select Mode Memory button.




- Select an empty one touch button




- Name the job (i.e. marketing doc, newsletter, etc...)



- The One Touch Destination is now registered



- Select Mode Memory button from Home Screen, then select the One Touch to activate the Saved Settings



*This function can also be used for scanning. In Fax/Scan mode you will be setting up a One Touch for scan settings instead of copy settings.